4. Block Diagram

4-1 CD Part




MM-S8/80/ZS8 BLOCK DIAGRAM
HISTORY
LCD
LCD DRIVER
MICOM
LC877348
VOL._SW
TACT_SW
REMYE
TUNER CONTROL
CDP CONTROL
TAPE CONTROL
AUX
R
L
TUNER
PACK
L-CH
R-CH
CD PACK
TAPE
DECK
L-OUT
R-OUT
L-IN(REC)
R-IN(REC)
MIC
AUX L
TUNER L
CD L
TAPE L
AUX R
TUNER R
CD R
TAPE R
TDA7440
FIC1
E. VOL
FIC2
FIC3
H/P AMP
HIC1
H/P JACK
POWER
AMP
IC6
FRONT L-CH
6 OHM
(25W)
FRONT R-CH
6 OHM
(25W)
LPF
IC7
SUB WOOFER
3 OHM
(50W)
FOCUS
TruBass
3D Stereo
NJM2700G
WIC1
AC INPUT
POWER TRANS
RCTIFIER
&
REGULATOR
OVER VOLTAGE DETECTOR
MODEL
MM-S8/S80/ZS8
DESIGNER
H.K. SIM
APP/DATE
03.04.21
FOR USE